

**BATTERY REQUIREMENTS:** This product requires 2 "AAA" standard alkaline batteries (not included). The use of heavy duty or rechargeable batteries is NOT recommended.

**INSTALL BATTERY:** Remove black portion of main unit. Slide battery cover off. Install 2 fresh alkaline "AAA" batteries. Replace battery cover. Snap black portion back onto rear of main unit.

**AUTO OFF:** To conserve power, the unit will power off when these conditions are met:

1. "Current Temperature" is less than 95°F (35°C);
2. "Current Temperature" has changed less than 35.6°F (2°C) in a 40 minute period.

**INSTRUCTIONS FOR USE:**

1. Temperatures display in degrees Fahrenheit (°F) by default. Degrees can be changed to Celsius (°C) using the switch located in the battery compartment.
2. Press the "ON/OFF" button to power on.
3. Use the "+" or "-" buttons to set target temperature for the alarm to sound. Press and hold "+" or "-" for rapid scroll.
4. Insert probe into thickest part of meat or fowl. Be sure tip is not touching bone, gristle, the pan or inserted into cavity of fowl.
5. Alarm sounds once meat has reached the target temperature.
6. Clean probe after each use to prevent cross-contamination.

**CARE INSTRUCTIONS:** Wash the probe with hot, soapy water after each use. The main unit and display area are **NOT WATERPROOF. DO NOT SUBMERGE IN WATER OR PLACE IN DISHWASHER.** Wipe with a soft, damp cloth. Use a VERY small amount of dishwashing soap if necessary to de grease the housing.

**Para Reemplazo de las Baterías:** Retire la parte posterior de la unidad principal. Retire la cubierta de las baterías deslizándola. Reemplace con 2 baterías alcalinas "AAA" nuevas. Coloque nuevamente la cubierta de las baterías. Inserte la parte posterior en el reverso de la unidad principal.

**Apagado Automático:** Para conservar energía, la unidad se apagará cuando se den estas condiciones:

1. La "Temperatura Actual" sea menor a 35°C (95°F) .
2. La "Temperatura Actual" haya cambiado a menos de 2°C (35.6°F) en un período de 40 minutos.

**Instrucciones de Uso:**

1. De forma predeterminada las temperaturas se muestran en grados Fahrenheit(°F). Se puede cambiar a grados Celsius (°C) usando el interruptor ubicado en el compartimiento de baterías.
2. Presione el botón "ON/OFF" para encender.
3. Use los botones "+" ó "-" para fijar la temperatura deseada para que suene la alarma. Mantenga presionado "+" ó "-" para avanzar rápidamente.
4. Inserte la sonda dentro de la parte más gruesa de la carne o ave. Asegúrese que la punta no toque hueso, cartílagos, la bandeja o que esté insertada en una cavidad del ave.
5. La alarma sonará una vez que la carne ha alcanzado la temperatura prefijada.
6. Limpie la sonda después de cada uso para evitar la contaminación entre alimentos.

**Instrucciones para el cuidado:** Lave la sonda con agua caliente y jabón luego de cada uso. La unidad principal y el área de visualización NO SON RESISTENTES AL AGUA. NO LAS SUMERJA EN AGUA NI LAS COLOQUE EN EL LAVAVAJILLAS. Limpie con un paño suave ligeramente humedecido. Si es necesario use una MUY pequeña cantidad de jabón de lavavajillas para desengrasar la cubierta



[www.AcuRite.com](http://www.AcuRite.com)



(877) 221-1252

**YOUR PRODUCT MUST BE REGISTERED TO RECEIVE WARRANTY SERVICE  
REGISTER YOUR PRODUCT AT [www.AcuRite.com](http://www.AcuRite.com)**