





The Solar Radiation Shield optimizes temperature and humidity readings by shielding compatible sensors from direct exposure to the sun.



1 INSERT SENSOR

Press sensor firmly into the Solar Radiation Shield's internal clips until it snaps into place.



2 PLACEMENT OPTIONS

Hang sensor using the integrated hang hole or hanger, or by using string (not included) to hang it from a suitable location, like a well covered branch.