This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:
1- This device may NOT cause harmful interference
2- This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, There is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.

PLEASE DISPOSE OF OLD OR DEFECTIVE BATTERIES IN AN ENVIRONMENTALLY SAFE WAY AND IN ACCORDANCE WITH YOUR LOCAL LAWS AND REGULATIONS.

BATTERY SAFETY: Clean the battery contacts and also those of the device prior to battery installation. Remove batteries from equipment which is not to be used for an extended period of time. Follow the polarity (+/-) diagram in the battery compartment. Promptly remove dead batteries from the device. Dispose of used batteries properly. Only batteries of the same or equivalent type as recommended are to be used. DO NOT incinerate used batteries. DO NOT dispose of batteries in fire, as batteries may explode or leak. DO NOT mix old and new batteries or types of batteries (alkaline/standard). DO NOT recharge non-rechargeable batteries. DO NOT short circuit the power supply terminals.

Limited 1-Year Warranty

AcuRite is a business unit and brand of Combex, Inc. (referred to as "Combex," "we," "us," or "our" in this document. Chaney Instrument Company is also a business unit and brand of Combex. For purchases of both AcuRite and Chaney Instrument Company products, Combex provides the benefits and warranty services described below.

We warrant to the original purchaser that all products we manufacture under this warranty are of good material and workmanship and, when properly installed and operated, will be free of defects for a period of one year from the date of purchase (the "One Year Warranty"). Any product which, under normal use and service and after examination by us, fails to meet the One Year Warranty will, at our sole option, be repaired or replaced by us. Although, as explained below, in some cases a refund will be provided. Transportation costs and charges for returned goods shall be paid for by the purchaser. We hereby disclaim all responsibility for such transportation costs and charges. The One Year Warranty does not cover, and we will not repair or replace products which have received normal wear and tear not affecting the functionality of the product, been damaged (including by acts of nature), tampered, abused, improperly installed, or repaired or altered by anyone other than our authorized representatives. The remedy under the One Year Warranty is limited to repair or replacement of the defective item(s). If we determine that repair or replacement is not feasible, we may, at our option, refund the amount of the original purchase price.

THE ONE YEAR WARRANTY IS NOT TRANSFERABLE AND IS THE SOLE WARRANTY FOR THE PRODUCTS AND IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. ALL OTHER WARRANTIES OTHER THAN THE EXPRESS WARRANTY SET FORTH HEREIN ARE HEREBY EXPRESSLY DISCLAIMED, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTY OF MERCHANTABILITY AND THE IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE. We expressly disclaim all liability for special, consequential, or incidental damages, whether arising in tort or by contract from any breach of this warranty. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. We further disclaim liability from personal injury relating to our products to the extent permitted by law. By acceptance of any of our products, the purchaser assumes all liability for the consequences arising from their use or misuse. No person, firm or corporation is authorized to bind us to any other obligation or liability in connection with the sale of our products. Furthermore, no person, firm or corporation is authorized to modify or waive the terms of this warranty unless done in writing and signed by a duly authorized agent of ours. In no case shall our liability for any claim relating to our products, your purchase or your use thereof, exceed the original purchase price paid for the product.

Applicability of Warranty The One Year Warranty applies only to purchases made in the United States and Canada. For purchases made in a country other than the United States or Canada, please consult the warranties, if any, applicable to the country in which you made your purchase. As noted, the One Year Warranty applies only to the original purchaser of our products. We cannot and do not offer any return, refund, or warranty services if you buy products used or from resale sites such as eBay or Craigslist.

Governing Law The One Year Warranty is governed by the laws of the United States and the State of Wisconsin. Any dispute relating to the warranty shall be brought exclusively in the federal or State courts having jurisdiction in Walworth County, Wisconsin; and purchaser consents to jurisdiction within the State of Wisconsin.

U.S. BASED SUPPORT
AcuRite.com/Support

Thank you for Choosing AcuRite.

ACU·RITE SINCE 1943

13131A5 INST26 06072026

ACU·RITE


www.AcuRite.com

LCD ALARM CLOCK


model # 13131A5

Thank You for purchasing this ACURITE® Alarm Clock product. To have the best possible experience with this product, please read this instruction manual in its entirety and keep this manual for future reference.

ALARM CLOCK CONTROLS



DISPLAY FEATURES



AM/PM INDICATORS
ONLY available when 12 Hr. time display option is selected

ALARM ON/OFF and ALARM VOLUME indicators

Calendar Display

Indoor Temperature
°C/°F Temperature Units Select Button is located within the Battery Compartment

Auto Dim Backlight ON indicator
ONLY available when USB Power is supplied

Indoor Temperature TREND indicators


FLEXIBLE POWER OPTIONS

Your new alarm clock has flexible power options to fit your life! There are two distinct power options:

AA **BATTERY POWER:** The alarm clock is primarily intended to be powered by 3 x AA alkaline batteries (not included). For maximum battery efficiency in battery power mode, the backlight will only function MOMENTARILY for a few seconds when the "Snooze/backlight" button is depressed.

USB-C **USB POWER:** The alarm clock can be optionally powered via USB-C cable (not included) and USB 5v 1A power supply (not included). When powered with a USB-C cable and power adapter, the backlight is will be constantly on, with an option to DIM the backlight 3 levels utilizing the "Snooze/Light" button. The third DIMMER setting will indicate "AUTO DIM" on the display, which will automatically DIM the display at night and go full brightness during the day.

NOTE: in USB POWER configuration, you may still install 3 x AA batteries as BACKUP POWER in case of a power interruption or power failure. The USB cable/adapter will NOT charge AA batteries in the battery compartment, the clock will simply switch over to AA battery configuration during a power interruption to the USB power input.



GENERAL SPECIFICATIONS

Power Requirements: 3 x AA Alkaline Batteries
OR USB-C cable and 5v 1a power supply
(DO NOT use rechargeable, Lithium, or Heavy Duty Batteries)

Temperature Measurement Range: 32° to 99°F (0 ° to 37°C)

MAX Alarm Volume: 70db (measured 3 feet away)

Dimensions: 7" wide x 5" tall x 2.375 depth

SETUP and USE

CURRENT TIME/GENERAL SETUP

Press AND HOLD the "set TIME" button for 3 seconds to enter into current time set general setup mode. When in SET mode, press the "▼" or "▲" buttons to adjust the currently flashing variable. Then, press the "SET Clock" button to confirm and move on to the next setting option.

CURRENT TIME/GENERAL SETUP Setting Order:
1.12 hr. or 24 hr. Time Display
2. Current Hour
3. Current Minute (12 Hr. time display mode only)
4. Current MONTH
5. Current DATE
6. Current YEAR
7. AUTOMATICALLY adjust for D.S.T. (DAYLIGHT SAVING TIME) - YES or NO

ALARM TIME Setting

Press AND HOLD the "set ALARM" button for 3 seconds to enter into ALARM TIME SET MODE. When in ALARM SET mode, press the "▼" or "▲" buttons to adjust the currently flashing variable. Then, press the "SET ALARM" button to confirm and move on to the next setting option.

ALARM TIME Setting Order:
1.Alarm Time HOUR
2.Alarm Time MINUTE

NOTE: PRESS AND RELEASE the "set ALARM" button to VIEW the CURRENTLY SET ALARM TIME

TO Turn Alarm Clock ON or OFF

TO TURN ALARM ON: slide the "Alarm on/off" switch to the "ON" position.
TO TURN ALARM OFF: slide the "Alarm on/off" switch to the "OFF" position.
ALARM INDICATOR: the display will indicate "Alarm ON"/ "Alarm OFF"

Alarm Clock SNOOZE function

When the alarm is sounding, you may activate the 8 minute SNOOZE function by firmly pressing down on the backlight/snooze area at the top of the alarm clock. The SNOOZE function may be activated up to 10 times.

BACKLIGHT control

BATTERY POWER MODE: Press the "Backlight/Snooze" button for 5 second momentary backlight.
USB POWER OPTION: Press the "Backlight/Snooze" button repeatedly to cycle through the backlight DIMMER modes: 100%, 60%, 30%, Auto Dim (dimmest overnight from 9:00 PM to 9:00 AM, brightest during the day)

ALARM VOLUME adjustment

You may adjust the alarm volume level by pressing the "▼" or "▲" buttons to increase or decrease the alarm volume respectably. Note the alarm volume level indicator.

www.AcuRite.com

U.S. BASED SUPPORT
AcuRite.com/Support