SMART SENSE

17017

Wi-Fi TEMPERATURE & HUMIDITY COMFORT MONITOR

www.AcuRite.com


BATTERY REQUIREMENTS: This product requires three "AAA" standard alkaline batteries (not included). DO NOT use heavy duty or rechargeable batteries.

WARNING: Batteries may pose a choking hazard, keep away from small children and animals.

INSTALL 3 AAA BATTERIES (not included):
On the back of the unit, press gently and slide the battery cover OFF in the direction of the arrow to remove.

Install 3 AAA batteries, aligning with the (+) positive and (-) negative symbols in the battery compartment and replace the battery compartment cover.

NOTE: you do not need to set the clock on the display, as soon as the device is connected to the internet, the clock will automatically be set.



TO TOGGLE BETWEEN °F/°C TEMPERATURE UNITS ON THE DISPLAY, DOUBLE CLICK THE BACKLIGHT BUTTON.

PLACE THIS MONITOR ANYWHERE INDOORS TO MONITOR TEMPERATURE AND HUMIDITY READINGS
The on-screen temperature and humidity readings can help you to make everyday decisions about the people, pets, or items inside your home. There is also an on-screen comfort guide that will let you know if the current humidity/temperature range is considered to be in the "COMFORT" range.

Wi-Fi FEATURES
This device can be quickly and easily connected to your home Wi-Fi to provide information remotely, change or update select on-screen settings, view your home information from anywhere, and set and receive alerts right on your mobile device! You can also explore records and charts and share with friends and family members.

Wi-Fi SETUP (standard 2.4 GHz Wi-Fi network compatible)
To add your new device to your home Wi-Fi, begin by simply downloading the **AcuRite NOW mobile app** from the App store on your mobile phone. After creating your account, press the "+" (add device) button on the upper right of the main page. The AcuRite NOW app will guide you through adding your new device. Then, explore the features and start enjoying the convenience of being able to view data from your new device on your mobile phone anytime you want to!

DOWNLOAD THE "AcuRite NOW" APP ON YOUR MOBILE PHONE

AcuRite NOW

INDOOR USE ONLY, FOR USE IN DRY ENVIRONMENTS. NO USER SERVICEABLE PARTS INSIDE.

SPECIFICATIONS

TEMPERATURE RANGE	14°F to 140°F (-10°C to 60°C) - (indoor use)
HUMIDITY RANGE	0% to 99% - (indoor use)
POWER REQUIREMENTS	3 x AAA Alkaline Batteries (will last ~ 6-8 months)
Wi-Fi COMPATIBILITY	2.4 GHz ONLY, requires a broadband connection
UPDATE FREQUENCY	5 MINUTE updates on AcuRite NOW
DISPLAY/BACKLIGHT	2.25" LCD with momentary 10 second backlight
°F/°C ON-DISPLAY UNITS	°F/°C temperature DISPLAY units option; DOUBLE click the backlight button to toggle between °F/°C units
CLOCK DISPLAY	12/24 hour clock DISPLAY option; TRIPLE click the backlight button to toggle between 12/24 hr Clock

THIS PRODUCT FEATURES A SECURE Wi-Fi CONNECTION TO "AcuRite NOW"

AcuRite NOW

TO ENJOY THE FULL FEATURES AND BENEFITS OF THIS PRODUCT, DOWNLOAD THE "AcuRite NOW" APP ON YOUR MOBILE PHONE

U.S. BASED SUPPORT
AcuRite.com/Support

TROUBLESHOOTING

DISPLAY NOT CONNECTING TO Wi-Fi	• Your internet router and display must be within range of each other. Relocate your display closer to your Wi-Fi router. • Ensure the network name (SSID) and password you've entered are correct. NOTE: Both network name and password are case sensitive. • Make sure DHCP is enabled on your router. Most routers have DHCP enabled by default. • Ensure your router is broadcasting a 2.4 GHz network. The comfort plus display only supports 2.4 GHz wireless (nearly all home routers broadcast 2.4 / 5 GHz by default) • Try adding your display again utilizing the AcuRite NOW app on your mobile device. Download the App and follow the on-screen instructions.
INACCURATE READINGS	• Make sure the unit is placed away from any heat sources or vents • Make sure the unit is positioned away from moisture sources • AcuRite products are factory calibrated to be within the possible accuracy range. What are you comparing readings with? If it is an older device, note that even though the readings of the comparable device may be trusted in the past, note that the readings typically drift well out of accuracy over time.
DISPLAY IS DIFFICULT TO READ OR APPEARS TO BE OFF	• LCD type displays have specific optimal viewing angles, usually looking at the display from a few feet away and slightly down at it will yield the best viewing contrast and visibility. • In low light areas, the display may be difficult to read. press the "BACKLIGHT" button located on the top of the housing to provide 10 sec. of light for low light viewing. • The display requires a constant source of power to operate continuously. Ensure the unit has fresh batteries and that they are correctly installed. • The batteries could be low on power or completely dead. Note that alkaline batteries are recommended for use ABOVE 32°F, if this unit is being used below 32°F, LITHIUM batteries are recommended. • The display itself may temporarily stop functioning or be dimmer below 32°F or above 95°F. •There could also be excess condensation in areas that alternate between temperature extremes, which is considered a WET installation environment and is NOT recommended to place this unit in WET areas.

CARE INSTRUCTIONS: Regularly gently clean the intake vents on the back of the unit to prevent obstructed intake. Do not clean the unit with abrasive or corrosive compound. Wipe the unit with a soft, damp cloth. The housing and display area are NOT WATERPROOF. DO NOT SUBMERGE IN WATER OR PLACE IN DISHWASHER. Do not subject the unit to excessive force, shock, temperature, direct sunlight, heavy exposure to water or humidity which may result in malfunction, shorter electronic life span, battery damage or distorted parts. There are no user serviceable internal components, do not open the housing to attempt to service internal components as this will void the warranty.

FC **This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:**
1- This device may NOT cause harmful interference
2- This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, There is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.

Limited 1-Year Warranty

AcuRite is a business unit and brand of Combex, Inc. (referred to as "Combex," "we," "us," or "our" in this document. Chaney Instrument Company is also a business unit and brand of Combex. For purchases of both AcuRite and Chaney Instrument Company products, Combex provides the benefits and warranty services described below. We warrant to the original purchaser that all products we manufacture under this warranty are of good material and workmanship and, when properly installed and operated, will be free of defects for a period of one year from the date of delivery (the "One Year Warranty"). Any product which, under normal use and service and after examination by us, fails to meet the One Year Warranty will, at our sole option, be repaired or replaced by us. Although, as explained below, in some cases a refund will be provided. Transportation costs and charges for returned goods shall be paid for by the purchaser. We hereby disclaim all responsibility for such transportation costs and charges. The One Year Warranty does not cover, and we will not repair or replace products which have received normal wear and tear not affecting the functionality of the product, been damaged (including by acts of nature), tampered, abused, improperly installed, or repaired or altered by anyone other than our authorized representatives. The remedy under the One Year Warranty is limited to repair or replacement of the defective item(s). If we determine that repair or replacement is not feasible, we may, at our option, refund the amount of the original purchase price.

THE ONE YEAR WARRANTY IS NOT TRANSFERABLE AND IS THE SOLE WARRANTY FOR THE PRODUCTS AND IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. ALL OTHER WARRANTIES OTHER THAN THE EXPRESS WARRANTY SET FORTH HEREIN ARE HEREBY EXPRESSLY DISCLAIMED, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTY OF MERCHANTABILITY AND THE IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE. WE EXPRESSLY DISCLAIM ALL LIABILITY FOR SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, WHETHER ARISING IN TORT OR BY CONTRACT FROM ANY BREACH OF THIS WARRANTY. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU. WE FURTHER DISCLAIM LIABILITY FROM PERSONAL INJURY RELATING TO OUR PRODUCTS TO THE EXTENT PERMITTED BY LAW. BY ACCEPTANCE OF ANY OF OUR PRODUCTS, THE PURCHASER ASSUMES ALL LIABILITY FOR THE CONSEQUENCES ARISING FROM THEIR USE OR MISUSE. NO PERSON, FIRM OR CORPORATION IS AUTHORIZED TO BIND US TO ANY OTHER OBLIGATION OR LIABILITY IN CONNECTION WITH THE SALE OF OUR PRODUCTS. FURTHERMORE, NO PERSON, FIRM OR CORPORATION IS AUTHORIZED TO MODIFY OR WAIVE THE TERMS OF THIS WARRANTY UNLESS DONE IN WRITING AND SIGNED BY A DULY AUTHORIZED AGENT OF OURS. IN NO CASE SHALL OUR LIABILITY FOR ANY CLAIM RELATING TO OUR PRODUCTS, YOUR PURCHASE OR YOUR USE THEREOF, EXCEED THE ORIGINAL PURCHASE PRICE PAID FOR THE PRODUCT.

Applicability of Warranty
The One Year Warranty applies only to purchases made in the United States and Canada. For purchases made in a country other than the United States or Canada, please consult the warranties, if any, applicable to the country in which you made your purchase. As noted, the One Year Warranty applies only to the original purchaser of our products. We cannot and do not offer any return, refund, or warranty services if you buy products used or from resale sites such as eBay or Craigslist.

Governing Law
The One Year Warranty is governed by the laws of the United States and the State of Wisconsin. Any dispute relating to the warranty shall be brought exclusively in the federal or State courts having jurisdiction in Walworth County, Wisconsin; and purchaser consents to jurisdiction within the State of Wisconsin.

** *******