

# Thermometer

model 00307



### Features & Benefits

- 1. Current Temperature**  
Arrow icon indicates direction temperature is trending.
- 2. High Temperature Record**  
Highest temperature recorded over the past 24 hours.
- 3. Low Battery Indicator**
- 4. Low Temperature Record**  
Lowest temperature recorded over the past 24 hours.
- 5. Battery Access**

### Install or Replace Battery

The thermometer includes a pre-installed CR-2032 battery. Remove the plastic insulator tab to activate the battery and thermometer display.

1. To replace the battery, insert a coin into the slot located on the bottom of the thermometer, and gently twist the coin to open the battery compartment.
2. Remove and safely discard the old battery. Insert 1 x CR-2032 coin cell battery into the battery compartment with the "+" positive terminal facing OUT.
3. Align the battery compartment cover with the thermometer and gently press together until the cover snaps into place.

### Select Temperature Units

To select between degrees Fahrenheit (°F) or Celsius (°C) temperature units, slide the "°C/°F" switch located inside the battery compartment. Follow "Replace Battery" steps above to gain access to the battery compartment.

### High & Low Records

Daily high and low records are displayed for indoor temperature. The records automatically clear every 24 hours since the battery was installed.

### Placement for Maximum Accuracy

AcuRite products are sensitive to surrounding environmental conditions. Placement in a proper location is critical to the accuracy and performance of this product. Place the thermometer in a dry area, free of dirt and dust. To ensure accurate temperature measurement, place the thermometer out of direct sunlight and away from any heat sources or vents. The thermometer features a magnetic backing for placement on magnetic surfaces.

# Specifications

<b>TEMPERATURE RANGE</b>	32°F to 122°F; 0°C to 50°C
<b>POWER</b>	1 x CR-2032 battery (included)



## **PLEASE DISPOSE OF OLD OR DEFECTIVE BATTERIES IN AN ENVIRONMENTALLY SAFE WAY AND IN ACCORDANCE WITH YOUR LOCAL LAWS AND REGULATIONS.**

**BATTERY SAFETY:** Clean the battery contacts and also those of the device prior to battery installation. Remove batteries from equipment that is not to be used for an extended period of time. Follow the polarity (+/-) diagram in the battery compartment. Promptly remove dead batteries from the device. Dispose of used batteries properly. Only batteries of the same or equivalent type as recommended are to be used. DO NOT incinerate used batteries. DO NOT dispose of batteries in fire, as batteries may explode or leak. DO NOT mix old and new batteries or types of batteries (alkaline/standard). DO NOT use rechargeable batteries. DO NOT recharge non-rechargeable batteries. DO NOT short-circuit the supply terminals.

**Questions?** Contact Customer Support at  
(877) 221-1252 or visit [www.AcuRite.com](http://www.AcuRite.com).

# IMPORTANT

**PRODUCT MUST BE REGISTERED  
TO RECEIVE WARRANTY SERVICE**

## **PRODUCT REGISTRATION**

Register online to receive 1 year warranty protection

[www.AcuRite.com](http://www.AcuRite.com)

## **Limited 1-Year Warranty**

AcuRite is a wholly owned subsidiary of Chaney Instrument Company. For purchases of AcuRite products, AcuRite provides the benefits and services set forth herein. For purchases of Chaney products, Chaney provides the benefits and services set forth herein.

We warrant that all products we manufacture under this warranty are of good material and workmanship and, when properly installed and operated, will be free of defects for a period of one year from the date of purchase.

Any product which, under normal use and service, is proven to breach the warranty contained herein within ONE YEAR from date of sale will, upon examination by us, and at our sole option, be repaired or replaced by us. Transportation costs and charges for returned goods shall be paid for by the purchaser. We hereby disclaim all responsibility for such transportation costs and charges. This warranty will not be breached, and we will give no credit for products which have received normal wear and tear not affecting the functionality of the product, been damaged (including by acts of nature), tampered, abused, improperly installed, or repaired or altered by others than our authorized representatives.

Remedy for breach of this warranty is limited to repair or replacement of the defective item(s). If we determine that repair or replacement is not feasible, we may, at our option, refund the amount of the original purchase price.

**THE ABOVE-DESCRIBED WARRANTY IS THE SOLE WARRANTY FOR THE PRODUCTS AND IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. ALL OTHER WARRANTIES OTHER THAN THE EXPRESS WARRANTY SET FORTH HEREIN ARE HEREBY EXPRESSLY DISCLAIMED, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTY OF MERCHANTABILITY AND THE IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.**

We expressly disclaim all liability for special, consequential, or incidental damages, whether arising in tort or by contract from any breach of this warranty. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

We further disclaim liability from personal injury relating to our products to the extent permitted by law. By acceptance of any of our products, the purchaser assumes all liability for the consequences arising from their use or misuse. No person, firm or corporation is authorized to bind us to any other obligation or liability in connection with the sale of our products. Furthermore, no person, firm or corporation is authorized to modify or waive the terms of this warranty unless done in writing and signed by a duly authorized agent of ours.

In no case shall our liability for any claim relating to our products, your purchase or your use thereof, exceed the original purchase price paid for the product.

### **Applicability of Policy**

This Return, Refund, and Warranty Policy applies only to purchases made in the United States and Canada. For purchases made in a country other than the United States or Canada, please consult the policies applicable to the country in which you made your purchase.

Additionally, this Policy applies only to the original purchaser of our products. We cannot and do not offer any return, refund, or warranty services if you buy products used or from resale sites such as eBay or Craigslist.

### **Governing Law**

This Return, Refund, and Warranty Policy is governed by the laws of the United States and the State of Wisconsin. Any dispute relating to this Policy shall be brought exclusively in the federal or State courts having jurisdiction in Walworth County, Wisconsin; and purchaser consents to jurisdiction within the State of Wisconsin.

©Chaney Instrument Co. All rights reserved. AcuRite is a registered trademark of the Chaney Instrument Co., Lake Geneva, WI 53147. All other trademarks and copyrights are the property of their respective owners. AcuRite uses patented technology. Visit [www.AcuRite.com/patents](http://www.AcuRite.com/patents) for details.